

Марка	Код двигателя	КВ	Л.с.	Год
ASKAM KAMYON Fargo Hi-Ex Series AS 32.300	MAN D0836 LFL01	215	292	09.2003-->
ASKAM KAMYON Fargo Hi-Ex Series AS 26.300	MAN D0836 LFL01	215	292	09.2003-->
ASKAM KAMYON Fargo Hi-Ex Series AS 19.300	MAN D0836 LFL01	215	292	09.2003-->
ERF ECL-Serie 7.28 RD3/TP3	MAN D0836	205	280	09.2000-->
ERF ECM-Serie 7.28 RD2/RR3/RDRS3	MAN D0836	205	280	09.2000-->
IKARUS 400-Serie 411	MAN D 0826	198	270	01.1994-->
KAELBLE SL10-Serie 14 B	MAN D0826		180	11.1992-->
MAN BUSSE (NEOMAN) Ale Ale Minibus	D 0834 LOH 01	125	170	09.2000-->
MAN BUSSE (NEOMAN) HOCL/FOCL (Bus-Chassis) 8.170 FOC	D 0826	128	174	10.1992-10.1993
MAN BUSSE (NEOMAN) HOCL/FOCL (Bus-Chassis) 10.180 HOCL	D 0826 TOH	135	183	01.1988-05.1992
MAN BUSSE (NEOMAN) HOCL/FOCL (Bus-Chassis) 11.150 HOCL	D 0826 OH02	97	132	05.1992-02.1993
MAN BUSSE (NEOMAN) HOCL/FOCL (Bus-Chassis) 11.190 HOCL	D 0826 LOH02	140	190	04.1992-02.1993
MAN BUSSE (NEOMAN) HOCL/FOCL (Bus-Chassis) 11.220 HOCL	D 0826 LOH/LUH	162	221	10.1995-->
MAN BUSSE (NEOMAN) HOCL/FOCL (Bus-Chassis) 11.230 HOCL	D 0826 LOH	169	230	04.1993-06.2001
MAN BUSSE (NEOMAN) HOCL/FOCL (Bus-Chassis) 13.220 HOCL	D 0826 LOH/LUH	162	221	10.1995-->
MAN BUSSE (NEOMAN)	D 0836 LOH02	206	280	09.2001-->

HOCL/FOCL (Bus-Chassis) 14.280 HOCL				
MAN BUSSE (NEOMAN) HOCL/FOCL (Bus-Chassis) 18.220 HOCL	D 0826 LOH/LUH	162	221	09.2000-->
MAN BUSSE (NEOMAN) HOCL/FOCL (Bus-Chassis) 10.220 FOC/FOCL	D 0826 LFL03	162	220	02.1995-->
MAN BUSSE (NEOMAN) Lion's City / City C / L / LL (NL-Series) NL 263 Hybrid	D 0836 LOH 63 EEV		260	09.2008-->
MAN BUSSE (NEOMAN) Lion's City / City C / L / LL (NL-Series) NL 202	D 0826 LUH	184	250	09.1989- 05.1997
MAN BUSSE (NEOMAN) Lion's City / City C / L / LL (NL-Series) NL 222	D 0826 LUH12	162	221	12.1995-->
MAN BUSSE (NEOMAN) Lion's City / City C / L / LL (NL-Series) NL 223	D 0826	161	220	01.1999-->
MAN BUSSE (NEOMAN) Lion's City / City C / L / LL (NL-Series) NL 223 F	D 0826	161	220	01.1999-->
MAN BUSSE (NEOMAN) Lion's City / City C / L / LL (NL-Series) NL 263	D 0826	191	260	01.1999-->
MAN BUSSE (NEOMAN) Lion's City / City C / L / LL (NL-Series) NL 263 F	D 0826	191	260	01.1999-->
MAN BUSSE (NEOMAN) Lion's City / City C / L / LL (NL-Series) NL 283	D 0836 LOH40	206	280	09.2002-->
MAN BUSSE (NEOMAN) Lion's City / City C / L / LL (NL-Series) NL 313	D 0826	227	310	01.1999-->
MAN BUSSE (NEOMAN) Lion's City / City C / L / LL (NL-Series) NL 243	D 0836 LOH	176	240	09.2002-->
MAN BUSSE (NEOMAN) Lion's City / City C / L / LL (NL-Series) NL 263	D 0836 LOH EEV	191	260	09.2006-->
MAN BUSSE (NEOMAN) Lion's City / City M (NM-Series) NM 263	D 0836 LOH 62/63 EEV		260	10.2006-->
MAN BUSSE (NEOMAN) Lion's City / City M (NM-Series) NM 243	D 0836 LOH52		240	11.2005-->
MAN BUSSE (NEOMAN) Lion's City /	D 0836 LOH		280	11.2005-->

City M (NM-Series) NM 283	40/51			
MAN BUSSE (NEOMAN) Lion's City / City M (NM-Series) NM 253	D 0836 LOH61 EEV/Euro 6		250	10.2009-->
MAN BUSSE (NEOMAN) Lion's City / City M (NM-Series) NM 293	D 0836 LOH60 EEV/Euro 6		290	10.2009-->
MAN BUSSE (NEOMAN) Lion's City / City M (NM-Series) NM 152	D 0824 LOH01	114	155	04.1992-->
MAN BUSSE (NEOMAN) Lion's City / City M (NM-Series) NM 152 Midi	D 0826 OH02	112	152	05.1990- 10.1993
MAN BUSSE (NEOMAN) Lion's City / City M (NM-Series) NM 182 Midi	D 0826 LOH	138	188	05.1990-->
MAN BUSSE (NEOMAN) Lion's City / City M (NM-Series) NM 192 Midi	D 0826 LOH	140	190	10.1993-->
MAN BUSSE (NEOMAN) Lion's City / City M (NM-Series) NM 223 Midi	D 0836 LOH	162	220	09.2000-->
MAN BUSSE (NEOMAN) Lion's City / City M (NM-Series) NM 224 Lions Midi	D 0836 LOH	162	220	03.2001-->
MAN BUSSE (NEOMAN) Lion's City / City M (NM-Series) NM 283 Midi	D 0836 LOH	206	280	09.2000-->
MAN BUSSE (NEOMAN) Lion's City / City M (NM-Series) NM 284 Lions Midi	D 0836 LOH	206	280	03.2001-->
MAN BUSSE (NEOMAN) Lion's City / City M (NM-Series) NM 223	D 0826 LOH15	162	221	08.1987-->
MAN BUSSE (NEOMAN) Lion's City G / GL / GLX (NG-Series) NG 263	D 0826	191	260	01.1999-->
MAN BUSSE (NEOMAN) Lion's City G / GL / GLX (NG-Series) NG 272	D 0826 LUH	198	270	06.1990- 09.1999
MAN BUSSE (NEOMAN) Lion's City G / GL / GLX (NG-Series) NG 313	D 0826	227	310	01.1999-->
MAN BUSSE (NEOMAN) Lion's City LE/LEÜ/T/TÜ (EL/EM-Series) EL 263 EEV	D 0836 LOH63		260	09.2007-->
MAN BUSSE (NEOMAN) Lion's City LE/LEÜ/T/TÜ (EL/EM-Series) EL 283	D 0836 LOH40		280	09.2004-->

MAN BUSSE (NEOMAN) Lion's City LE/LEÜ/T/TÜ (EL/EM-Series) EL 223	D 0836 LOH		220	09.2004-->
MAN BUSSE (NEOMAN) Lion's City LE/LEÜ/T/TÜ (EL/EM-Series) EL 293	D 0836 LOH 60 EEV / Euro 6		290	09.2008-->
MAN BUSSE (NEOMAN) Lion's City LE/LEÜ/T/TÜ (EL/EM-Series) EL 202, EL 202F	D 0826 LUH	157	214	11.1992-->
MAN BUSSE (NEOMAN) Lion's City LE/LEÜ/T/TÜ (EL/EM-Series) EL 222 F	D 0826 LUH12	162	221	05.1997-->
MAN BUSSE (NEOMAN) Lion's City LE/LEÜ/T/TÜ (EL/EM-Series) EL 262, 262 F	D 0826 LUH13	191	260	01.1996-->
MAN BUSSE (NEOMAN) Lion's City LE/LEÜ/T/TÜ (EL/EM-Series) EM 222	D 0826 LUH12	162	221	02.1996-->
MAN BUSSE (NEOMAN) Lion's City LE/LEÜ/T/TÜ (EL/EM-Series) EM 192 Europa-Midi	D 0826 LOH06	140	190	10.1993-09.1997
MAN BUSSE (NEOMAN) Lion's City LE/LEÜ/T/TÜ (EL/EM-Series) EM 223	D 0826 LOH15	162	221	08.1987-->
MAN BUSSE (NEOMAN) Lion's City UE / Lions City UELL (NUE-Series) NUE 263	D 0826	191	260	01.1999-10.2001
MAN BUSSE (NEOMAN) Lion's City UE / Lions City UELL (NUE-Series) NUE 313	D 0826	227	310	01.1999-->
MAN BUSSE (NEOMAN) Lion's City UE / Lions City UELL (NUE-Series) NUE 223	D 0826	161	220	01.1999-->
MAN BUSSE (NEOMAN) Lion's Classic (SL-Series) SL 223	D 0836	162	220	03.2000-->
MAN BUSSE (NEOMAN) Lion's Classic (SL-Series) SL 283	D 0836	206	280	03.2000-->
MAN BUSSE (NEOMAN) Lion's Classic UE (SUE-Series) SUE 223	D 0826	162	221	08.1999-->
MAN BUSSE (NEOMAN) Lion's Classic UE (SUE-Series) SUE 283	D 0836 LOH	206	280	09.2001-->

MAN BUSSE (NEOMAN) Midi Beta Midi Beta (11.190 HOCL)	D 0826 LOH06	140	190	03.1993- 09.1995
MAN BUSSE (NEOMAN) SM (Midi) SM 152 Midi	D 0826 OH02	97	132	11.1987- 04.1994
MAN BUSSE (NEOMAN) SM (Midi) SM 182 Midi	D 0826 TOH	132	180	11.1987- 04.1991
MAN BUSSE (NEOMAN) SM (Midi) SM 192 Midi	D 0826 TOH	137	186	05.1988- 02.1995
MAN CLA Cargo Line A (06-) 16.220	D0836		220	10.2006-->
MAN CLA Cargo Line A (06-) 15.220	D0836		220	10.2006-->
MAN CLA Cargo Line A (06-) 25.280	D0836		280	10.2006-->
MAN CLA Cargo Line A (06-) 20.280	D0836		280	10.2006-->
MAN CLA Cargo Line A (06-) 14.160	D0834	114	155	10.2006-->
MAN CLA Cargo Line A (06-) 18.160	D0834	114	155	10.2006-->
MAN CLA Cargo Line A (06-) 18.180	D0834	132	179	10.2006-->
MAN CLA Cargo Line A (06-) 18.280	D0836	206	280	10.2006-->
MAN CLA Cargo Line A (06-) 18.220	D0836	162	220	10.2006-->
MAN CLA Cargo Line A (06-) 26.280	D0836	206	280	10.2006-->
MAN CLA Cargo Line A (06-) 26.220	D0836	162	220	10.2006-->
MAN ENGINES D08-Serie D0824				
MAN ENGINES D08-Serie D0826				
MAN G90 (87-95) 6.100 F	D 0824 GF, GF01		102	09.1987- 12.1992
MAN G90 (87-95) 10.150 F	D 0826 GF01		150	09.1987- 12.1992
MAN G90 (87-95) 10.153 F	D 0824 LFL01		155	10.1993- 01.1995
MAN G90 (87-95) 10.223 F	D 0826 LFL02		230	10.1993- 05.1994
MAN G90 (87-95) 9.150 F	D 0826 GF		150	09.1987-

				12.1992
MAN G90 (87-95) 9.153 F	D 0824 LFL01		155	10.1993-01.1995
MAN G90 (87-95) 9.223 F	D 0826 LFL02		220	10.1993-05.1994
MAN G90 (87-95) 8.100 F	D 0824 GF, GF01		102	09.1987-12.1992
MAN G90 (87-95) 8.103 F	D 0824 FL01		102	10.1993-01.1995
MAN G90 (87-95) 8.150 F	D 0826 GF		150	09.1987-12.1992
MAN G90 (87-95) 8.153 F	D 0824 LFL01		155	10.1993-01.1995
MAN G90 (87-95) 8.223 F	D 0826 LFL02		230	10.1993-05.1994
MAN L2000 + L2000 Evolution (94-) 8.113 L	D 0824 LFL04	81	110	08.1995-->
MAN L2000 + L2000 Evolution (94-) 8.150 FOC	D 0824 LFO	118	160	04.1995-->
MAN L2000 + L2000 Evolution (94-) 8.163 F	D 0824 LFL02	118	160	05.1994-->
MAN L2000 + L2000 Evolution (94-) 8.185 L	D 0834	132	180	05.2001-->
MAN L2000 + L2000 Evolution (94-) 8.145 L	D 0834	103	140	05.2001-->
MAN L2000 + L2000 Evolution (94-) 8.220 FOC	D 0826 LFL03/06/10	162	220	04.1995-->
MAN L2000 + L2000 Evolution (94-) 8.224 F	D 0826 LFL03/06/10	162	220	05.1994-->
MAN L2000 + L2000 Evolution (94-) 8.225 L	D 0836	162	220	05.2001-->
MAN L2000 + L2000 Evolution (94-) 9.145 L	D 0834	103	140	05.2001-->
MAN L2000 + L2000 Evolution (94-) 9.163 F	D 0824 LFL02	118	160	05.1994-->

MAN L2000 + L2000 Evolution (94-) 9.185 L	D 0834	132	180	05.2001-->
MAN L2000 + L2000 Evolution (94-) 9.224 F	D 0826 LFL03/06/10	162	220	05.1994-->
MAN L2000 + L2000 Evolution (94-) 9.225 L	D 0836	162	220	05.2001-->
MAN L2000 + L2000 Evolution (94-) 10.145 L	D 0834	103	140	05.2001-->
MAN L2000 + L2000 Evolution (94-) 10.185 L	D 0834	132	180	05.2001-->
MAN L2000 + L2000 Evolution (94-) 10.163 F	D 0824 LFL02	118	160	05.1994-->
MAN L2000 + L2000 Evolution (94-) 10.150 FOC	D 0824 LFO	118	160	04.1995-->
MAN L2000 + L2000 Evolution (94-) 10.224 F	D 0826 LFL03	162	220	05.1994-->
MAN L2000 + L2000 Evolution (94-) 10.225 L	D 0836	162	220	05.2001-->
MAN L2000 + L2000 Evolution (94-) 8.223 L	D 0826 LFL06	162	220	05.1994-->
MAN LE (2000-2007) LE 140 C	D 0834	103	140	01.2001-->
MAN LE (2000-2007) LE 180 C	D 0834	132	180	01.2001-->
MAN LE (2000-2007) LE 220 C	D 0836	162	220	01.2001-->
MAN LE (2000-2007) LE 110 C	D 0824 LFL06	83	113	08.2000-->
MAN LE (2000-2007) LE 160 C	D 0824 LFL08	114	155	08.2000-->
MAN LE (2000-2007) LE 220 C	D 0826 LFL10	162	220	08.2000-->
MAN LE (2000-2007) LE 220 B	D 0826 LFL10	162	220	09.2000-->
MAN LE (2000-2007) LE 220 B	D 0836	162	220	01.2001-->
MAN LE (2000-2007) LE 250 B	D 0836	180	245	01.2001-->
MAN LE (2000-2007) LE 280 B	D 0836	206	280	01.2001-->
MAN M2000 + M2000 Evolution (94-)	D 0834	103	140	05.2001-->

12.145 L				
MAN M2000 + M2000 Evolution (94-) 12.163 L	D 0824 LFL06	114	155	08.1995-->
MAN M2000 + M2000 Evolution (94-) 12.185 L	D 0834	132	180	05.2001-->
MAN M2000 + M2000 Evolution (94-) 12.224 L	D 0826 LFL03/06/10	162	220	05.1994-->
MAN M2000 + M2000 Evolution (94-) 12.225 L	D 0836	162	220	05.2001-->
MAN M2000 + M2000 Evolution (94-) 12.255 L	D 0836	180	245	05.2001-->
MAN M2000 + M2000 Evolution (94-) 12.264	D 0826 LF17	191	260	11.1998-->
MAN M2000 + M2000 Evolution (94-) 12.284	D 0836LF	206	281	11.1998-->
MAN M2000 + M2000 Evolution (94-) 14.163 L	D 0824 LFL06	114	155	08.1995-->
MAN M2000 + M2000 Evolution (94-) 14.185 L/M	D 0834	132	180	05.2001-->
MAN M2000 + M2000 Evolution (94-) 14.224 L/M	D0826 LFL03/10/15/18	162	220	08.1995-->
MAN M2000 + M2000 Evolution (94-) 14.225 L/M	D 0836	162	220	05.2001-->
MAN M2000 + M2000 Evolution (94-) 14.255 L	D 0836	180	245	05.2001-->
MAN M2000 + M2000 Evolution (94-) 14.264 L/M	D 0826 LFL09/17	191	260	08.1995-->
MAN M2000 + M2000 Evolution (94-) 14.284 L/M	D 0836 LFL01	206	280	11.1998-->
MAN M2000 + M2000 Evolution (94-) 14.285 L/M	D 0836	206	280	05.2001-->
MAN M2000 + M2000 Evolution (94-) 15.163 L	D 0824 LFL06	114	155	08.1995-->
MAN M2000 + M2000 Evolution (94-) 15.185 L	D 0834	103	140	05.2001-->

MAN M2000 + M2000 Evolution (94-) 15.224 L	D 0826 LFL03/10	162	220	08.1995-->
MAN M2000 + M2000 Evolution (94-) 15.225 L	D 0836	162	220	05.2001-->
MAN M2000 + M2000 Evolution (94-) 15.255 L	D 0836	180	245	05.2001-->
MAN M2000 + M2000 Evolution (94-) 15.284 L	D 0836 LFL01	206	281	07.1998-->
MAN M2000 + M2000 Evolution (94-) 15.264 L	D 0826 LFL09	191	260	08.1995-->
MAN M2000 + M2000 Evolution (94-) 15.285 L	D 0836	206	280	05.2001-->
MAN M2000 + M2000 Evolution (94-) 18.224 L	D 0826 LFL03/10	162	220	08.1995-->
MAN M2000 + M2000 Evolution (94-) 18.225 L/M	D 0836	162	220	05.2001-->
MAN M2000 + M2000 Evolution (94-) 18.255 L/M	D 0836	180	245	05.2001-->
MAN M2000 + M2000 Evolution (94-) 18.284 L/M	D 0836 LFL01	206	280	11.1998-->
MAN M2000 + M2000 Evolution (94-) 18.285 L/M	D 0836	206	280	05.2001-->
MAN M2000 + M2000 Evolution (94-) 18.264 L	D 0826 LFL09/LF17	191	260	08.1995-->
MAN M2000 + M2000 Evolution (94-) 20.224 L	D 0826 LFL10	162	221	09.1997-->
MAN M2000 + M2000 Evolution (94-) 20.225 L	D 0836	162	220	05.2001-->
MAN M2000 + M2000 Evolution (94-) 20.255 L	D 0836	180	245	05.2001-->
MAN M2000 + M2000 Evolution (94-) 20.264 L	D 0826 LFL09	191	260	09.1997-->
MAN M2000 + M2000 Evolution (94-) 20.284 L	D 0836 LFL01	206	280	11.1998-->
MAN M2000 + M2000 Evolution (94-)	D 0836	206	280	05.2001-->

20.285 L				
MAN M2000 + M2000 Evolution (94-) 23.284 L	D 0836 LF	206	284	11.1998-->
MAN M2000 + M2000 Evolution (94-) 25.225 M	D 0836	162	220	05.2001-->
MAN M2000 + M2000 Evolution (94-) 25.224 M	D 0826 LF15/18	162	220	08.1995-->
MAN M2000 + M2000 Evolution (94-) 25.255 M	D 0836	180	245	05.2001-->
MAN M2000 + M2000 Evolution (94-) 25.264 M	D 0826 LF17	191	260	08.1995-->
MAN M2000 + M2000 Evolution (94-) 25.284 M	D 0836 LF01	206	280	11.1998-->
MAN M2000 + M2000 Evolution (94-) 25.285 M	D 0836	206	280	05.2001-->
MAN M2000 + M2000 Evolution (94-) 26.224 L	D 0826 LF/LFL	162	220	09.1997-->
MAN M2000 + M2000 Evolution (94-) 26.225 L	D 0836	162	220	05.2001-->
MAN M2000 + M2000 Evolution (94-) 26.255 L	D 0836	180	245	05.2001-->
MAN M2000 + M2000 Evolution (94-) 26.284 L	D 0836 LFL01	206	280	05.1999-->
MAN M2000 + M2000 Evolution (94-) 26.285 L	D 0836	206	280	05.2001-->
MAN M2000 + M2000 Evolution (94-) 19.264	D 0826 LF17/LFL09	162	220	08.1995-->
MAN ME (2000-2007) ME 260 B	D 0836		260	08.2000- 04.2007
MAN ME (2000-2007) ME 220 B	D 0836	162	220	08.2000-->
MAN ME (2000-2007) ME 250 B	D 0836	180	245	08.2000-->
MAN ME (2000-2007) ME 280 B	D 0836	206	280	08.2000-->
NEOPLAN (NEOMAN) Centroliner / Centroliner Evolution N 4407	D 0826 LOH17	162	220	10.1998-->

NEOPLAN (NEOMAN) Centroliner / Centroliner Evolution N 4411	D 0826 LOH17/LUH12	162	220	10.1998-->
NEOPLAN (NEOMAN) Centroliner / Centroliner Evolution N 4416	D 0826 LOH17/LUH12	162	220	10.1998-->
NEOPLAN (NEOMAN) Centroliner / Centroliner Evolution N 4416	D 0836 LOH03	206	280	10.1998-->
NEOPLAN (NEOMAN) Centroliner / Centroliner Evolution N 4411	D 0836 LOH03	206	280	10.1998-->
NEOPLAN (NEOMAN) Centroliner / Centroliner Evolution N 4416	D 0836 LUH13	191	260	01.1999-12.2001
O+K ORENSTEIN + KOPPEL (CNH) MH/RH-Serie 12 PMS	MAN D0826L		210	01.1994-->
O+K ORENSTEIN + KOPPEL (CNH) MH/RH-Serie 16 PMS	MAN D0826L		220	01.1991-->
OPTARE Solo / Solo SE / Solo SR M880	MAN D0834 Euro4		177	09.2006-->
OPTARE Solo / Solo SE / Solo SR M810	MAN D0834 Euro4		177	09.2006-->
OPTARE Solo / Solo SE / Solo SR M780	MAN D0834 Euro4		177	09.2006-->
OPTARE Solo / Solo SE / Solo SR M710	MAN D0834 Euro4		177	09.2006-->
OPTARE Solo / Solo SE / Solo SR M950	MAN D0834 Euro4		177	09.2006-->
OPTARE Solo / Solo SE / Solo SR M1020	MAN D0834 Euro4		177	09.2006-->
OPTARE Solo / Solo SE / Solo SR M890	MAN D0834 LOH50 Euro4		177	10.2007-->
OPTARE Solo / Solo SE / Solo SR M960	MAN D0834 LOH50 Euro4		177	10.2007-->
OPTARE Tempo X1060	MAN D0836 LOH51 Euro4		280	09.2006-->
OPTARE Tempo X1130	MAN D0836 LOH51 Euro4		280	09.2006-->
OPTARE Tempo X1200	MAN D0836		280	09.2006-->

	LOH51 Euro4			
OPTARE Tempo X1260	MAN D0836 LOH51 Euro4		280	09.2006-->
OPTARE Versa V 1040	MAN D0834 Euro4		177	09.2006-->
OPTARE Versa V 1110	MAN D0834 Euro4		177	09.2006-->
OTOKAR Vectio 250 LE, S, T, U	MAN D0836 LOH65		250	04.2007-->
PEGASO (ENASA) Superligeros Ekus 1200-Serie 1210.6	D 0824 GF/D 0826 GF			
PEGASO (ENASA) Superligeros Ekus 1200-Serie 1215.8	D 0824 GF/D 0826 GF			
PEGASO (ENASA) Superligeros Ekus 1200-Serie 1215.9	D 0224 GF/D 0826 GF			
PEGASO (ENASA) Superligeros Ekus 1200-Serie 1215.10	D 0824 GF/D 0826 GF			
ROMAN S.A. (DAC) 16t-Serie 16.245 F	MAN D0836 LFL05	180	245	02.2005-->
ROMAN S.A. (DAC) 18t-Serie 18.245 FL	MAN D0836 LFL05	180	245	02.2005-->
ROMAN S.A. (DAC) 18t-Serie 18.280 FL	MAN D0836 LFL03	206	280	02.2005-->
ROMAN S.A. (DAC) 26t-Serie 26.280 DFAE	MAN D0836 LFL	206	281	01.1999-->
SCHLUETER Euro Trac-Serie 1400	MAN D0826 TUE501		135	01.1997-->
SCHLUETER Euro Trac-Serie 1700	MAN D0826 LUE503		169	01.1997-->
SCHLUETER Euro Trac-Serie 2000	MAN D0826 LUE501		200	01.1997-->
SCHLUETER Euro Trac-Serie 800				01.1990-->
SCHLUETER Euro Trac-Serie 1000				01.1990-->
SCHLUETER Euro Trac-Serie 1150				01.1990-->

SCHLUETER Euro Trac-Serie 1300				01.1990-->
SCHLUETER Euro Trac-Serie 1600				01.1990-->
SCHLUETER Euro Trac-Serie 1900				01.1990-->
SOLARIS Urbino U 12	MAN D 0826 LOH18		260	01.1999-->
SOLARIS Urbino U 9	MAN D 0824 LOH05	114	155	01.1999-->
SOLARIS Urbino U 12	MAN D 0824 LOH17	162	221	01.1999-->
SOLARIS Urbino U 15	MAN D 0826 LOH18	191	260	01.1999-->
SOLARIS Urbino U 18	MAN D 0824 LOH25	191	260	01.1999-->
STAR TRUCKS 10t-Serie 10.157	D0824 LFL09	114	155	01.2001-->
STAR TRUCKS 12t-Serie 12.155	D0824 LFL09	114	155	11.1998-->
STAR TRUCKS 12t-Serie 12.157	D0824 LFL09	114	155	01.2001-->
STAR TRUCKS 12t-Serie 12.227	D0826 LFL10	162	221	01.2001-->
STAR TRUCKS 1400-Serie 1466	D0826 LFLG15	162	221	01.1998-->
STAR TRUCKS 15t-Serie 15.227	D0826 LFL10	162	221	01.2001-->
STAR TRUCKS 8t-Serie 8.125	D0824 LFL10	92	155	11.1998-->
STAR TRUCKS 8t-Serie 8.117	D0824 LFL08	83	113	01.2001-->
STAR TRUCKS 900-Serie 944	D0824 LFL09	114	155	01.1998-->
STEYR 10 S 10 S 14	MAN D 0834	103	140	05.2001-->
STEYR 10 S 10 S 16	MAN D 0824	114	155	09.1991-->
STEYR 10 S 10 S 18	MAN D 0834	132	180	05.2001-->
STEYR 10 S 10 S 22	MAN 0826	162	220	05.1994-->
STEYR 12 S 12 S 14	MAN D 0834	103	140	05.2001-->
STEYR 12 S 12 S 16	MAN D 0824	114	155	09.1991-->

STEYR 12 S 12 S 18	MAN D 0834	132	180	05.2001-->
STEYR 12 S 12 S 22	MAN 0826	162	220	05.1994-->
STEYR 12 S 12 S 28	MAN D 0836	206	280	11.1998-->
STEYR 12 S 12 S 25	MAN D 0836	180	245	05.2001-->
STEYR 14 S 14 S 16	MAN D 0824	114	155	09.1991-->
STEYR 14 S 14 S 18	MAN D 0834	132	180	05.2001-->
STEYR 14 S 14 S 25	MAN D 0836	180	245	05.2001-->
STEYR 14 S 14 S 22	MAN D 0826	162	220	08.1995-->
STEYR 14 S 14 S 26	MAN D 0826	191	260	08.1995-->
STEYR 14 S 14 S 28	MAN D 0836	206	280	11.1998-->
STEYR 15 S 15 S 16	MAN D 0824	114	155	09.1991-->
STEYR 15 S 15 S 18	MAN D 0834	132	180	05.2001-->
STEYR 15 S 15 S 26	MAN D 0826	191	260	08.1995-->
STEYR 15 S 15 S 28	MAN D 0836	206	280	11.1998-->
STEYR 15 S 15 S 22	MAN D 0826	162	220	05.1994-->
STEYR 15 S 15 S 25	MAN D 0836	180	245	05.2001-->
STEYR 18 S 18 S 22	MAN D 0826	162	220	05.1994-->
STEYR 18 S 18 S 28	MAN D 0836	206	280	11.1998-->
STEYR 18 S 18 S 25	MAN D 0836	180	245	05.2001-->
STEYR 19 S 19 S 22	MAN D 0826	162	220	05.1994-->
STEYR 19 S 19 S 25	MAN D 0836	180	245	05.2001-->
STEYR 19 S 19 S 28	MAN D 0836	206	280	11.1998-->
STEYR 20 S 20 S 22	MAN D 0826	162	220	05.1994-->
STEYR 20 S 20 S 25	MAN D 0836	180	245	05.2001-->
STEYR 20 S 20 S 28	MAN D 0836	206	280	11.1998-->

STEYR 25 S 25 S 22	MAN D 0826	162	220	05.1994-->
STEYR 25 S 25 S 25	MAN D 0836	180	245	05.2001-->
STEYR 25 S 25 S 28	MAN D 0836	206	280	11.1998-->
STEYR 26 S 26 S 22	MAN D 0826	162	220	05.1994-->
STEYR 26 S 26 S 25	MAN D 0836	180	245	05.2001-->
STEYR 26 S 26 S 28	MAN D 0836	206	280	11.1998-->
STEYR 6 S 6 S 16	MAN D 0824	114	155	09.1991- 12.1993
STEYR 6 S 6 S 10	MAN D 0824	75	102	09.1991- 12.1993
STEYR 8 S 8 S 10	MAN D 0824	75	102	09.1991-->
STEYR 8 S 8 S 16	MAN D 0824	114	155	09.1991-->
STEYR 8 S 8 S 11	MAN D 0824	81	110	08.1995-->
STEYR 8 S 8 S 18	MAN D 0834	132	180	05.2001-->
STEYR 8 S 8 S 22	MAN 0826	162	220	05.1994-->
STEYR 8 S 8 S 14	MAN D 0834	103	140	05.2001-->
STEYR 9 S 9 S 14	MAN D 0834	103	140	05.2001-->
STEYR 9 S 9 S 16	MAN D 0824	114	155	09.1991-->
STEYR 9 S 9 S 18	MAN D 0834	132	180	05.2001-->
STEYR 9 S 9 S 22	MAN 0826	162	220	05.1994-->
TEMSA MD9 MD9C	MAN D0836 LOH65 E5/EEV		250	10.2010-->
TEMSA Metropol Metropol Intercity	MAN D0834 LOH51	152	206	10.2006-->
TEMSA Metropol Metropol Intercity	MAN D0836 LOH52	176	240	10.2006-->
TEMSA Opalin Opalin 8	MAN D0834 LOH51	152	206	09.2005-->
TEMSA Opalin Opalin 9	MAN D0836	176	240	09.2005-->

	LOH52			
TEMSA Samba Samba	MAN D 0834 LFL03	132	180	01.2001-->
TROUILLET GT-Serie GT 36	MAN-D 0826	140	190	09.1991-->
VAN HOOL A3, AG3, AGG3 A308	MAN D0836 LOH		239	05.2006-->
VAN HOOL A500 A500	MAN D0826 LOH217		230	03.1996-->
VAN HOOL A500 A500	MAN D0826 LOH04		218	01.1985-->
VAN HOOL T8, TD8, TG8 T809 Alizee	D 0826 OH02		132	10.1978- 12.1996
VAN HOOL T8, TD8, TG8 T809 Alizee	D 0826 LOH		190	09.1990- 12.1998